


Installation Manual

DAIHATSU TERIOS 5DR
DAI-TERI-5-A



COMPONENTS INCLUDED



CL-M02 x 4



CL-P03 x 2



CL-M05 x 4



CL-P02 x 2



CL-W01 x 1

Installation

DAIHATSU TERIOS 5DR

DAI-TERI-5-A

